

# U-Anchor 2600 SBS Adhered

## Installation Instructions:

---

*\*These instructions are for Built-up and SBS roof systems.*

### **Before you start:**

Inspect the existing roof with a qualified professional to ensure that it is in good condition and meets local codes and manufacturer's warranty requirements.

### **Layout:**

Appropriate frequency and spacing of the attachment points should be determined by a qualified professional for seismic requirements, compressive strength of the roofing assembly, structural load capacity, and local building code requirements. The roof surface should be clean, free of foreign debris, and dry prior to the U-Anchor. Use a chalk line (blue non-permanent chalk) to convey designed layout on each side of the U-Anchor 2600 with the crosshatches previously prepared on the surface.

**Step 1:** Once properly aligned, outline the target area and remove the target. Secure the plate with approved fasteners, per engineering requirements.

**Step 2:** Prime the area and plate with a roofing manufacturer approved primer and allow to dry to the touch.

**Step 3:** Apply adhesive to the substrate with a trowel. (Check mfg.'s recommendations for thickness of adhesive.) Install the die cut asphalt target into the adhesive, pressing downward on the target to fully embed it in the adhesive. Allow a 1/4" bleed to occur on all edges.

**Step 4:** Apply loose granules over exposed adhesive. Install the 2" separator around the bolt. This can be adhered in place, but is not required.

*(Prior to adhering the Anchor mount into place, be sure the placement is accurate)*

Install ancillary components using a stainless steel 3/8"-16 nut and lock washer. The recommended torque for the U-Anchor 200 is 10 foot pounds.

